

**Work Order ID 96716**

**\*96716\***

Page 1

Monday, February 11, 2013 4:24:44 PM

Item ID:	D3849-041	Accept	<b>*N900040100*</b>	Setup	Start	<b>*NS1*</b>		
Revision ID:						Stop	<b>*NS2*</b>	
Item Name:	Fwd Wearplate Assembly, STD Gear							
Start Date:	1/31/2013	Start Qty:	1.00	<b>*1*</b>	Cust Item ID:			
Required Date:	2/1/2013	Req'd Qty:	1.00	<b>*1*</b>	Customer:	CU-DAR001		
Reference:	RMA RA111416 - RETURN							
Approvals:	Process Plan:	<i>MF</i>	Date: 13-2-11	Tooling:	Date:	Run	Start	<b>*NR1*</b>
	QC:		Date:	SPC (Y/N):	Date:	Stop		<b>*NR2*</b>

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr	Revision Nbr								
D3849	D								

100 0.00

**\*100\***

QC

Quality Control

Memo 0.00 DAS  
INSPECT RA 111416 D3849-041 X 1 B#52401 16 )  
13/2/12

PART IS SCRAP

110

**\*110\***

Small Fab

Small Fab

Memo 0.00

SCRAP PART

① Ø Ae 13-02-12

120

**\*120\***

QC

Quality Control

QC21- Final Inspection - Work Order Release 0.00

Memo 0.00

13/2/2012

MLS 13-02-12

# Picklist Print

Monday, February 11, 2013 4:24:43 PM

Page 1

**Work Order ID:** 96716  
**Parent Item:** D3849-041  
**Parent Item Name:** Fwd Wearplate Assembly, STD Gear  
**Start Date:** 1/31/2013      **Required Date:** 2/1/2013  
**Comments:** IPP RevA: New issue DD verified by:EC  
DWG REV.D DD VERF:JLM      IPP Rev:B 12.09.11 AS PER

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
D3849-041 Fwd Wearplate Assembly, STD Gear		Manufactured	No				Each	6.0000		1			

Location	Loc Qty	Loc Code
FP-001	2	
93152	2	
FP002	4	
90319	4	

2 x 52401

h